

## Thank you for shopping embe!

We appreciate your support of small businesses! Below are application and care instructions for your iron-on/heat transfer vinyl applique.



### Application instructions:

1. **Pre-wash** – Wash the material/item you will be adhering the applique to. This will allow the item to shrink (if any) to the appropriate size without distorting the vinyl.
2. **Pre-heat** – Pre-heat your iron to medium heat WITHOUT steam.
3. **Remove** – Remove the wax paper backing and position the applique to the desired position so that the vinyl is directly on your item; you will notice that the clear top plastic layer is slightly sticky underneath.
4. **Iron** – Use a light piece of cloth (like a T-shirt or tea towel) and lay over the applique. Press and hold iron for 8-10 seconds on each section until entire piece is bonded.
  - a. **TIP:** You can remove the cloth piece and quickly run the tip of your iron on top of plastic where the vinyl is to ensure that it is fully adhered.
5. **Remove** – Remove the clear plastic layer slowly and carefully.. Begin in one corner working your way across the applique. Should any part of the vinyl come up, put the plastic layer back down and quickly run the iron over it.
6. **Iron (again)** – For good measure, take the cloth piece you used earlier and place it on top of your applique. Run the iron over for another 10 seconds on each section.

**Care instructions:** For best results, wait 24 hours before washing.